


Original



# Installation And Service Manual



**Four Post Parking lift**  
**Model: A430-P**


# CONTENTS

Product Features and technical Specifications .....	1
Installation Requirement .....	2
Steps of Installation .....	4
Exploded View .....	29
Test Run .....	38
Operation Instruction .....	39
Maintenance .....	40
Trouble Shooting .....	41
Lift safety tips.....	41

## I. PRODUCT FEATURES AND SPECIFICATIONS

### 4-POST MODEL A430-P FEATURES

- Single cylinder drive, Cable drive.
- Single point manual safety release.
- The primary safety device of automatic machinery and the secondary safety device of cable breaking in the process of rising ensure the safety of the vehicle.
- Power-side column can be installed at both side, front or rear.
- Non-skid diamond platforms and adjustable safety lock ladders.
- Optional kits: Sliding jack with hand pump, caster kits, plastic oil tray.



**Fig. 1**

### MODEL A430-P SPECIFICATIONS

Model	Lifting Capacity	Lifting Height	Lifting Time	Overall Length (Inc. Ramps)	Overall Width	Overall high	Width Between Columns	Motor
A430-P	3000KG	2120mm	35S	4720mm	2409mm	2455mm	2167mm	110V: 1.5HP 220V: 3.0HP

## II. INSTALLATION REQUIREMENT

### A.TOOLS REQUIRED


✓Tape Measure (7.5m)



✓ Hammer



✓ Level Bar



✓ English Spanner (



✓ Wrench set: (12<sup>#</sup>、13<sup>#</sup>、14<sup>#</sup>、15<sup>#</sup>、17<sup>#</sup>、19<sup>#</sup>  
24<sup>#</sup>、30<sup>#</sup>)



✓ Carpenter's Chalk



✓ Screw Sets



✓ Pliers



✓ Lock Wrench



✓ Socket Head Wrench: (3<sup>#</sup>、5



Fig. 2

### B. Equipment storage and installation requirements.

The equipment should be stored or installed in a shady, normal temperature, ventilated and dry place.

**C. The equipment should be unload and transfer by forklift.**




**Fig.3**

**D.SPECIFICATIONS OF CONCRETE (See Fig. 4)**

**Specifications of concrete must be adhered to the specification as following.**

**Failure to do so may result in lift and/or vehicle falling.**

1. Concrete must be thickness 100mm minimum and without reinforcing steel bars, and must be dried completely before lift installation.
2. Concrete must be in good condition and must be of test strength  $210\text{kg/cm}^2$  (3,000psi) minimum.
3. Floors must be level and no cracks.



**Fig.4**

**E. POWER SUPPLY**

The electrical source must be 3.0HP minimum. The source cable size must be  $2.5\text{mm}^2$  minimum and in good condition of contacting with floor.

### III. STEPS OF INSTALLATION

#### A. Check the parts before assembly


1. Packaged lift and Hydraulic Power Unit (See Fig. 5).



**Fig. 5**


Optional Plastic oil tray

2. Open the outer packing carefully, check the parts according to the shipment list.  
(See Fig. 6)



**Fig. 6**

3. Take off the drive-thru ramps and columns (See Fig.7).




**Fig.7**

4. Loose the screws of the upper package stand, take off the offside platform, take out the parts inside the power-side platform, then remove the package stand.



5. Move aside the parts and check the parts according to the shipment parts list  
(See Fig. 8).



**Fig. 8**

6. Open the carton of parts and check the parts according to the parts box list  
(See Fig. 9)



**Fig. 9**


7. Check the parts of the parts bag according to the parts bag list (See Fig. 10).



B. Use a carpenter’s chalk line to establish installation layout as per Table 1

Make sure the size is right and base is flat (see Fig. 11).



**Note: Reserve space front and behind the installation site.**



MODEL	A	B	C
A430-P	3877mm	2409mm	4564mm




**C. Install cross beams (Note that Hole of the beam towards inside and the side with the rotating component of the safety mechanism should be the same side as the column where the power unit is installed. See Fig.12 & 13)**




#### D. Install the Safety Ladders.


1. Take off the pulley safety cover and unscrew a nut of the safety ladders, and then adjust the four lower nuts to be at the same position. Then install the safety ladder (**See Fig. 14**).



## 2.Install Safety Ladders (See Fig. 15).




## E.Put the cross beams at the same height and lock on the safety ladder (See Fig. 16).



## F. Install power side platform.

1. Install the power-side platform on the cross beams by a fork lift or manual, offset the cross beams to outside a little until the pulleys of both platforms enter into the cross beams opening (**See Fig.17**). Aligning holes on the power-side platform and cross beam, then screw up the bolts.




**2. Install tire stop plate with bolts and washer on the platform:** Tighten the platform on cross beam **B** with bolts, tighten the tire stop plate on cross beam **A** with bolts

**Note:** The bolts for the side with tire stop plate is longer, pay attention when choosing the bolts (**See Fig.18**)


**Instruction:** 1). This lift is designed in both side (cross beam **A** and cross beam **B**) car in direction, user can install the lift according to the location. Below is the installation for the side of cross beam **B** car in direction. If choosing the side of cross beam **A** car in direction, then install the tire stop plate to the other side.

2). Power-side column can be installed at any position on customers' requirement, but the power unit must be installed near the side with the safety lock release handle.



**Fig. 18**

**G. Install offside platform and plastic block, then install the bolts for the platform strengthen plate, check the plumbness of columns with level and adjusting with the shims (See Fig. 19)**




**Fig. 19**



**H. Illustration for cable installation**


1. Pass through the cables from the platform to the columns according to the number of the cables **(See Fig. 20)**




**Cable installation diagram**  
**Fig. 20**

NO.	①	②	③	④
Cable				
Length (inc. connecting fitting)	4264mm	9529mm	5684mm	8112mm


2. The cable goes through the cross beam to top plate of columns and be screwed with cable nuts (**See Fig. 21**). 17A



After the cable passes through the hole in the roof, cover the cable gasket and lock the nut. The cable adjusting sleeve (17B) does not need to be installed in the first use, and the cable may be elongated after loading , so the cable adjusting sleeve (17B) is used to adjust according to the actual need.




Cable pass through top plate and be screwed with cable nuts.



**Fig. 21**


3. Illustration for platform cables (**See Fig. 22**).




**Fig. 22**

## I. Install release handle assy. See Fig.23


Noted: Power unit must be installed near the safety release handle.



**Fig. 23**




Pass through the connecting bar from the safety lock rotated device of cross beam **A/B**




**View A**

According to the above diagram, fix lock release handle and the safety lock connecting with M8\*35 bolts and washers on cross beam **A**.



Install extend lock release handle and plastic ball




**View B**

According to the above diagram, fix safety lock connecting bar and safety lock connecting by M8\*35 bolts and washers on cross beam **B**.

## J. Install power unit and connecting tube (See Fig. 24).

Noted: Power unit must be installed near the safety release handle.

### 1. Install Power unit on the cross beam **A**




**Fig. 24**



## K. Install Hydraulic System

1. For power unit attached to the column of cross beam **A** (See Fig. 25)


**Note:** Oil hoses connected to oil cylinder must be passed above the cable to avoid the oil hose scratched by cable.



**Fig. 25**




**L. Install the control box and limit switch( See. Fig.26)**




**Fig. 26**

Note: When the cross beam goes to highest place, the cross beam slider touched the high limit switch drive bar and the lift stop rising. When the cross beam lower to 520mm from ground, the cross beam slide block touched the low limit switch drive bar and the lift stop lowering.

## 1. Wire connecting for high limit switch



## 2. Wire connecting for low limit switch wire




## M. Install Electrical System

1. Connecting wire with control box. ( See. Fig.27)

Note: 1) Specification of wire of limit switch and Air solenoid valve is  $2 \times 1^2$  .  
Specification of power source wire and motor wire :  $4 \times 2.5^2$ .

2) Using white bobbin to wind around wire.


3) Fix the cable of limit switch on the column with retainer, tie the wire with protective hose by the cable ties.



**Fig. 27**

## 2. 380V Wire connection and circuit diagram

### 2.1 Wire connection diagram in the control box (See Fig. 28)




**Fig.30**

### 2.2 Wire connection diagram of Three phase hydraulic motor (See Fig. 29).


Motor wire (M1,M2,M3) are connected to the three wires in the motor.

Turn on the power, push button "UP", if motor run but lift do not work, exchange the wire M1 and M2 connection.



**Fig.29**

### 2.3 380V Circuit diagram (See Fig. 30)




**Fig.30**

### 380V Circuit component

Item	Name	Code	Specification
1	Power switch	QS	380V AC
2	Breaker	FU <sub>1</sub>	16A
3	Breaker	FU <sub>2</sub>	6A
4	Breaker	FU <sub>3</sub>	2A
5	AC contactor	KM	24V AC
6	Hydraulic solenoid valve	Y	24V AC
7	Push button	UP	Single
8	Push button	Down	Single
9	Lowering alarm button	Pass	Duplex
10	Motor	M	3 phase
11	Transformer	TC	24V AC
12	High limit switch	SQ <sub>1</sub>	10A
13	Low limit switch	SQ <sub>2</sub>	10A
14	Buzzer	H	24V AC
15	Indicator light	R	24V


### 3. 220V Wire connection and circuit diagram

#### 3.1 Wire connection diagram in the control box (See Fig. 31)




#### 3.2 Wire connection of single phase hydraulic power unit( See fig.32)

Motor wire (M1,M2) separately connected to two terminals in the control box.



### 3.3 220V Circuit diagram (See Fig. 33)




**Fig.33**

#### 220V Circuit component

Item	Name	Code	Specification
1	Power switch	QS	380V AC
2	Breaker	FU <sub>1</sub>	25A
3	Breaker	FU <sub>2</sub>	6A
4	Breaker	FU <sub>3</sub>	6A
5	AC contactor	KM	24V AC
6	Solenoid valve	Y	24V AC
7	Push button	UP	Single
8	Push button	Down	Single
9	Lowering alarm button	Pass	Duplex
10	Motor	M	3 phase
11	Transformer	TC	24V AC
12	High limit switch	SQ <sub>1</sub>	10A
13	Low limit switch	SQ <sub>2</sub>	10A
14	Buzzer	H	24V AC
15	Indicator light	R	24V




**N. Install spring and safety cover of cross beam (See Fig. 34).**



**Fig.34**

**O. Install **Folding drive-in ramp**, optional jack tray and optional plastic oil pans (See Fig. 35).**

According to the below diagram screw up the M16\*30 bolts, then attach the drive-in ramp.




**Fig. 35**

## Folding Drive-in ramps Part List

Item	Part#	Description	QTY.
7-1	1104543020A	Folding Ramps 1	2
7-2	1104543021A	Folding Ramps 2	2
7-3	1104543021	Connecting Pin	4
7-4	10209010	φ10 Snap Ring	8

### P. Install Rear wheel stop plates (See Fig. 36)


After driving the vehicle on the lift, flip up the front part of the drive-in ramps.



**Fig. 36**

**Q. For optional kits installation.**

**1. Install optional caster kits (See Fig. 37)**




**Fig. 37**

Item	Part#	Description	QTY.	Note
73-1	11410042A	Support bracket	4	
73-2	10209125	Hex bolt	16	
73-3	10209039	Lock washer $\phi 10$	16	
73-4	10209022	Washer $\phi 10$	16	
73-5	10209021	Hex nut M10	16	
73-6	10410035	Plastic wheel	4	
73-7	11410034	Connecting pin $\phi 19 \times 216$	4	
73-8	10209012	Hair Pin $\phi 3.2$	8	


## R. Fix the anchor bolts

1.1 Prepare the anchor bolts (See Fig. 38).




1.2 Using the prescribed rotary hammer drill, and drill all the anchor holes and install the anchor bolts. Do not tighten the anchor bolts (See Fig. 39).

**Note: The tightening torque for the anchor bolt is 150N.m ,Anchor bolts driven into the ground at least 90mm**




## IV. EXPLODED VIEW

### Model A430-P



## Power-side platform



**Fig. 41**

### PARTS LIST FOR MODEL A430-P


Item	Part#	Description	QTY.	Note
1	11410002	Power-side Column	3	
2	11410001	Offside Column	1	
3	1104542001B	Cross Beam <b>A</b>	1	
4	1104543001B	Offside Platform	1	
5	1104543001A	Power-side Platform	1	
6	1104542001B	Cross Beam <b>B</b>	1	
7	1104543020C	Folding Drive-in ramp	2	
8	10201002	Hex Bolt M8*16	6	
9	10209033	Washer $\phi 8$	44	
10	10209005	Self locking Nut M8	28	
11	11423004	Cylinder fixed ring	1	
12	1004546000	Cylinder $\phi 80 \times 876$	1	
13	1104533013A-01	Piston rod connecting seat	1	



Item	Part#	Description	QTY.	Note
14	10410012	Hex Nut M24	1	
15	10201005	Split Pin $\phi 4 \times 50$	1	
16	81523021	Power Unit	1	
17	10420175A	Hex nut M20	8	
17A	10209066	Hex nut M16	8	
17B	1104541002	Adjusting sleeve of cable	4	
17C	1104541001	Cable gasket	4	
18	11410022	Safety ladder L=1974	4	
19	1104543009A	Pulley pin $\phi 30 \times 86.5$	4	
20	10481005	Washer $\phi 30$	21	
21	1104543011	Pulley $\phi 167 \times 16$	2	
22	1004542002	Bronze bush for pulley $\phi 36 \times \phi 30.1 \times 15$	6	
22A	10620141	Bronze bush $\phi 36 \times \phi 30.1 \times 24$	4	
23	10209034	Lock Washer $\phi 8$	22	
24	10410013	Hex Bolt M16*30	8	
25	10420137	Lock washer $\phi 16$	8	
26	10420029	Washer $\phi 16$	8	
27	10410014	Hex Bolt M16*35	4	
28	11410015-1	Tire stop plate	2	
29	10206006	Washer $\phi 12$	8	
30	10420026	Lock washer $\phi 12$	4	
31	10410105	Hex Bolt M12*20	4	
32	10410016A	Plastic block 81*38*38mm	16	
33	10410017	Socket bolt M8*40	16	
34	10201090	Shim(1mm)	20	
	10620065	Shim(2mm)	20	
35	1004543003	Cable ①	1	
36	1004543004	Cable ②	1	
37	1004543002	Cable ③	1	
38	1004543001	Cable ④	1	
39	85090099	Socket Bolt M10*90	2	
39A	85090332	Socket Bolt M10*70	1	
40	1104542009	Connecting bar for safety device $\phi 19 \times 1791 \text{mm}$	2	
41	11410024	Connecting tube	1	
42	10209032	Socket bolt M8*25	6	
43	10217005	Plastic ball M10	1	
43A	10209056	Self locking Nut M10	1	
44	10410025	Socket bolt M8*35	4	
45	11410026	Safety release handle	1	
45A	11410100	Extension lock release handle	1	
46	10209004	Rubber ring $\phi 8 \times \phi 20 \times 3$	4	
47	10209003	Hex Bolt M8*25	8	

Item	Part#	Description	QTY.	Note
47A	10209043	Hex Bolt M8*20	4	
47B	10217002	Hex Nut M8	4	
48	10420166	90° Fitting	1	
49	11420243	Straight Fitting for cylinder	1	
49A	11420245	Limit block	1	
49B	11209119	Compensation Valve	1	
49C	10201020	90°degree fitting	1	
50	1004543005	Oil hose	1	
51	10420120	Extend straight fitting with nut	1	
52	1004543008-01	Oil hose 1/4*1420mm	1	
53	10209060	90° Fitting for power unit	1	
54	10420095	Straight fitting	1	
55	1004543007	Oil return hose L=4962mm	1	
56	1004533008	Protective hose φ20*1*1400mm	1	
57	10209145A	Cup head bolt with washer M6*12	8	
58	1104542012	Plastic cover for cross beam	4	
59	1004542001	Spring φ14*2.0*50	4	
60	10410146	Spring φ14*2.0*75	4	
61	10209059	Anchor bolt 3/4*5-1/2	16	
62		Parts box	1	
63	1104551003	90 degree installation plate	1	
64	1004543006	Slider block 106*40*29	1	
65	1104533013A-01	Piston rod connecting seat	1	
65A	1104533017A-01	Pulley Pin φ25*77.5	2	
66	10640109	Washer Φ25.5*44*2	1	
67	10410114	Electric control box	1	
67A	10420045	Washer φ6	2	
67B	10209145	Cup head bolt M6×12	2	
67C	10410107	Wire for solenoid valve 2*1 <sup>2</sup> *900mm	1	
67D	10420168	Wrap Φ10×2000mm	1	
67E	10217135	Motor wire 4*2.5 <sup>2</sup> *900mm	1	
68	10206013	Limit switch	2	
68A	10206011	Cup Head Bolt M5×12	12	
68B	11420010A	Bracket of Limit switch	2	
68C	10410108	Wire of Limit switch 2*1 <sup>2</sup> *1200mm	2	
69	1104543016	Pulley adjusting sleeve φ40*4*18	1	
69A	1104543019	Pulley adjusting sleeve φ40*4*9	2	
70	1104543017	Pulley φ167*25	4	
71	1104533024	Cushion cover φ40*4*23	2	
<b>Optional kits</b>				
72	11410040	Jack tray	1	
73	1040801	Caster kits	4	
74	96600002	Jack J5H	1	
76	10410039	Plastic oil tray	4	


#### 4.1 Control box : 10410114 Three phase 10410178 Single Phase



**Fig. 42**

Item	Part#	Description	QTY.	Note
67-1	10420069A	Cover Of Control Box	1	
67-2	10201094	Power Indicator	1	
67-3	10420070	Button <b>UP</b>	1	
67-4	10420070	Button <b>Down</b>	1	
67-5	10420139	Screw	4	
67-6	10420074	Power Switch (QS1)	1	
67-7	10202047	Breaker 2P (3 phase)	1	
	10202046	Breaker 2P (Single phase)	1	
67-8	10202049	Breaker 2P	2	
67-9	10420134	Transformer (TC)	1	
67-10	10420084A	24V AC Contactor (KM)	1	
67-11	10620082	Connecting terminal	1	
67-12	10420133A	Panel for Installing Element	1	
67-13	10420073	Cup Head Bolt	4	
67-14	10420142	Lowering alarm button Pass	1	
67-15	10420143	Buzzer	1	
67-16	10420088	Fitting For White Wire Cable	4	

## 4.2 CYLINDERS (1004536000)




**Fig. 43**

### Parts For Cylinder

Item	Part#	Description	QTY.	Note
12-1	10420059	Dust ring $\Phi 30 \times \Phi 38 \times (5 \sim 6.5)$	1	
12-2	10420060	Y- Ring IDI $\Phi 30 \times \Phi 40 \times 8$	1	
12-3	11420061	End cover	1	
12-4	10420062	O- Ring $\Phi 81.5 \times 3.55$	1	
12-5	1004546001A	Cylinder components	1	
12-6	1104546002	Piston Rod	1	
12-7	11420065	Cylindrical pin	1	
12-8	10420066	Support Ring $\Phi 74 \times \Phi 80 \times 15 \times 3$	1	
12-9	10420067	Y- Ring OSI $\Phi 70 \times \Phi 80 \times 6$	1	
12-10	11420068	Piston	1	

### 4.3 CROSS BEAM (1104542001B)




**Fig.44**

#### Parts For cross beam

Item	Part#	Description	QTY.	Note
3-2	10206032	Snap Ring $\phi 25$	2	
3-3	10410099	Spring $\phi 14 \times \phi 2.5 \times 100$	2	
3-5	1104542008-01	Connecting bar for safety lock	2	
3-7	1104572003A	Safety lock rotated device assy.	2	
3-8	1104542011A-01	Connecting bar assy. for safety lock	2	
3-9	1104542006-01	Pulley Bush $\phi 30 \times 100$	4	
3-10	1104542007	Pulley pin sleeve $\phi 40 \times 4 \times 51.5$	4	
3-11	10209010	Snap ring $\phi 10$	4	
3-12	10420035	Tension pulley	4	
3-13	11420174	Spacer	4	
3-14	11420171	Pin	12	
3-15	11420175	Slack-cable safety lock (Left & Right)	2 each	
3-16	11420172	Pin Bush For Slack-cable safety lock	8	
3-17	10206019	Snap ring $\phi 19$	24	
3-18	10420037	Snap ring $\phi 16$	16	
3-19	11420038	Pin $\phi 16 \times 98$	8	
3-20	10420138	Socket Bolt M6*16	8	
3-21	10209149	Lock washer $\phi 6$	8	
3-22	10420045	Washer $\phi 6$	8	
3-23	11420044	Stop block	4	

#### 4.4 Manual Power Unit (81523021)



**Fig. 45**


#### Parts list for 220V/50Hz, Single Phase

Item	Part#	Description	Qty.	Note
1	81400180	Rubber Pad	2	
2	81400250	Start capacitor	1	
3	81400200	Run Capacitor	1	
4	10420148	Cup head bolt with washer	6	
5	81400066	Protective cover for capacitor	2	
6	81400363	Motor Connecting Shaft	1	
7	81400362	Manifold Block	1	
8	10209149	Lock Washer	4	
9	81400276	Hex iron plug	1	
10	81400259	Red Plastic Plug	1	
11	85090142	Socket bolt	4	
12	81400292	Gear pump	1	
13	10209034	Lock Washer	2	
14	81400295	Socket bolt	2	
15	81400365	O Ring	1	
16	10209152	Ties	1	
17	85090167	Magnet	1	
18	81400290	Filter net	1	
19	81400287	Motor	1	



Item	Part#	Description	Qty.	Note
20	81400287	Cover of Motor Terminal Box	1	
21	71111108	AMGO Nameplate	1	
22	81400560	Throttle valve	1	
23	81400266	Relief Valve	1	
24	81400284	Iron plug	1	
25	81400420	Solenoid valve coil	1	
26	81400423	Release valve(electrical)	1	
27	81400566	Check valve	1	
28	81400288	Inlet pipe	1	
29	81400289	Oil return pipe	1	
30	81400364	Hose clamp	1	
31	81400263	Oil tank cap	1	
32	81400320	Oil tank	1	


### Illustration of hydraulic valve for hydraulic power unit



**Fig.46**

## V. TEST RUN

1. Fill the reservoir with Hydraulic Oil (**Note:** In consideration of Power Unit's durability, please use **Hydraulic Oil 46#**).
2. Press the control button on the power unit till the cables are strained. Check the cables and confirm they are in the proper pulley position. Make sure the cables are not across.
3. Press the release valve handle on the power unit to lock the cross-beam on the safety ladders, and then adjust the platforms to be level by adjusting the nuts of safety ladders. Tighten the nuts above and under the safety ladder top plate after leveling.
4. Adjust the cable fitting hex nuts to make platforms and four safety locks work synchronously. You need to run the lift up and down for several times, meanwhile do the synchronous adjustment till the four safety devices can lock and release at the same time.
5. Adjust the clearance between the column and the plastic slider of cross-beam, make sure the plastic slider can be slid in the column smoothly. Do not tighten too much of the sliding block.
6. After finishing the above adjustment, test running the lift with load. Run the lift with platforms in low position first, make sure the platforms can rise and lower synchronously and the safety device can lock and release synchronously. And then test run the lift to the top completely. If there are anything improper, repeat the above adjustment.



**Fig. 47**

## VI. OPERATION INSTRUCTIONS

### To lift vehicle


1. Keep clean of environment near the lift.
2. Drive vehicle to the platform and put on the brake.
3. Take off the drive-in ramp, install rear wheel stop plates to the drive-in ramp position.
4. Turn on the power and press the control button, raise the lift to the working position.

**Note: make sure the vehicle is steady when the lift is raised.**

5. Press the release valve handle to lock the lift in the safety position. Make sure the safety device is locked at the same height.

### To lower vehicle

1. Be sure the clearance of around and under the lift, only leaving operator in lift area.
2. Press the control button, the lift will be raised for 3-5 seconds, and then press the safety release handle, make sure the safety device released, press the release valve handle by the other hand, then the lift starts being lowered automatically.
3. Drive away the vehicle when the lift is lowered to the lowest position. Take off the rear wheel stop plates and install drive-in ramp, then left the lift.
4. Turn off the power.



**Fig. 48**

## **VII. MAINTENANCE SCHEDULE**

### **Monthly:**

1. Lubricate cable with lubricant;
2. Check all cable connection, bolts and pins to insure proper mounting;
3. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage;
4. Lubricate all rollers, safety devices with 90wt. gear oil or equivalent.

### **Every six months:**

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check and adjust as necessary, equalizer tension to insure level lifting.
3. Check columns for plumbness.

### **Oil cylinder maintenance:**

In order to extend the service life of the oil cylinder, please operate according to the following requirements.

1. Recommend to use N46 anti-wear hydraulic oil.
2. The hydraulic oil of the lifts should be replaced regularly during using. Replace the hydraulic oil 3 months after the first installation, Replace the hydraulic oil once a year afterwards.
3. Make at least one full trip raising and lowering per day. For exhausting the air from the system, which could effectively avoid the corrosion of the cylinder and damage to the seals caused by presence of air or water in the system.
4. Protect the outer surface of the oil cylinder's piston rod from bumping and scratching, and timely clean up the debris on the oil cylinder dust-ring and the piston rod.

## VIII. TROUBLE SHOOTING

TROUBLE	CAUSE	REMEDY
Motor does not run	1. Button does not work 2. Wiring connections are not in good condition 3. Motor burned out 4. AC contactor burned out	1. Replace button 2. Repair all wiring connections  3. Repair or replace motor 4. Replace AC contactor
Motor runs but the lift is not raised	1. Motor runs in reverse rotation 2. Release valve in damage 3. Gear pump in damage 4. Relief valve or check valve in damage 5. Low oil level	1. Reverse two power wire 2. Repair or replace 3. Repair or replace 4. Repair or replace 5. Fill tank
Lift does not stay up	1. Release valve out of work 2. Relief valve or check valve leakage. 3. Cylinder or fittings leaks	Repair or replace
Lift raises too slow	1. Oil line is jammed 2. Motor running on low voltage 3. Oil mixed with Air 4. Pump leaks 5. Overload lifting	1. Clean the oil line 2. Check electrical system 3. Fill tank 4. Repair or replace pump 5. Check load
Lift cannot lower	1. Safety device are not in activated 2. Release valve damaged	1. Operate again 2. Repair or replace

## IX. SCARPING OF EQUIPMENT

Once the equipment is unusable and needs to be scarped, please follow the local laws and regulations.



## **PEAK CORPORATION**

No. 3 Luomu Road, Shishan Town, Nanhai District, Foshan(528225), Guangdong, China

Tel: 86-757-81102815 81102805

Fax: 86-757-81102809

Email: [peak@peaklift.cn](mailto:peak@peaklift.cn)      <http://www.peaklift.cn>

Manual Part No.: **72213402**

Revision Date: 2022/12